

# Olex keyboard shortcuts

F1	Jump
F2	Center
F3	Edge
F4	3D On - 3D Off
F5	Event mark
F6	Start Track recording
F7	End Track recording
F8	Bottom Zoom On - Bottom Zoom Off
F9	Depth Colour Range <<<
F10	Depth Colour Range >>>
F11	Relief On - Relief Off
F12	Depth Boxes On - Depth Boxes Off
Home	Center
Page Up	Zoom In
Page Down	Zoom Out
Arrow keys	Scroll vertically or horizontally

Keyboard/mouse combination:

Alt + Left Mouse Click      Create a mark at cursor